

Getting the most from “Critical Airflow” (VAV) Control Systems

By Ken Kolkebeck
Facility Diagnostics, Inc.

What is a VAV System?

- Any system where airflows are balanced (adjusted) dynamically in real-time
- They are the opposite of constant volume systems which are balanced once and then left alone
- Because of the impact on safety, they are referred to as “Critical Airflow Controls”
- Comment: How many constant volume systems are really constant?

About Variable Air Volume Control Systems-

- Principal goals are to
 - Reduce energy over life of building
 - Reduce capital cost
 - Provide flexibility over the life of building
 - Improve worker safety
- VAV Systems typically come in two types;
 - Full VAV; airflows are automatically adjusted over entire range of operation
 - Two Position; airflows are set at either high, or low values. Occupancy or use are most common “toggles” used to switch modes.

About Variable Air Volume Control Systems-


- Having been around for almost 15 years, the use of VAV in lab applications is widely accepted
- In the past decade, most new laboratory projects utilize some means of modulating (adjusting) airflow
- >\$100M of Specialized “Critical Airflow Control” hardware manufactured annually for labs
- Evidence shows users often feel they are not getting the energy savings expected

In this presentation we will discuss-

- Why “automatic” fume hood controls do not automatically save energy
- What factors often work against saving energy in lab buildings
- Why safety and energy conservation goals harmonize so well
- How to utilize control features hidden in your system
- How to use data available from the **Building Automation System** to optimize performance.
- How to get expert help; online and real-time.

Review of VAV Lab Basics-

■ Air flow through Lab




Understanding the Three Airflow Drivers-

- Minimum Air Changes
 - Safety Requirement
- Supply Air for Cooling
 - Comfort Requirement
- Supply Air for Hood Make-Up
 - Needed to replenish air exhausted by fume hoods


Lab Airflow Conditions-

- Small Room
 - 300 to 400 Sqr. Ft.
 - 10 to 12 ACH
- Large or Multiple Fume Hoods
 - 2, 8 ft Bench, 1250 ea.
- Moderate Heat Load
 - 3 to 15 Watts/Sqr. Ft.
- Good application




Lab Airflow Conditions-

- Large Room
 - 1000 to 2000 Sqr. Ft.
- Small Fume Hood
 - 1, 4 ft. Bench at 600
- Low Heat Load
 - 3 to 10 Watts/Sqr. Ft.
- Poor application




Lab Airflow Conditions-

- Small Room
 - 300 to 400 Sqr. Ft.
 - 10 to 12 ACH
- Small Fume Hood
 - 1, 6 ft Bench, 850 ea.
- High Heat Load
 - 10 to 30 Watts/Sqr. Ft.
- Good application



Infiltration air isn't free!



- Either way it costs the same
- Choose comfort..... or complaints!

Factors that work against meeting energy goals-

■ Fume Hood Habits

- People leave sashes open
 - During periods lab is occupied, while not at hoods
 - During unoccupied periods
- People use hoods with sashes wide open

■ Excessive Fume Hood Exhaust Air

- Maximum airflow determined at wide open sash rather than at “working height”

Factors that work against meeting energy goals- *.....continued*

- High heat loads in labs
 - Need for supply air for cooling eats into VAV fume hood savings
- Exhaust consumers are added without regard to where the air they need will come from
- Attitudes- the idea that safety and energy conservation impede creativity!

Safe Practices are Green Practices-

- These practices are supported by every standard and guide on the safe use of fume hoods-
 - Sashes are wide open only during setup and tear down of experiments
 - Glass panels are to be positioned between the experiment and the worker's breathing zone
 - Sashes are to be closed when the user leaves the front of the hood

Supporting “Sash Management”

- Develop a plan jointly with Safety, Facility, and R&D department management
- Educate and Train
 - Safe hood use practices
 - Sash use
 - Experiment setup
 - Energy conservation
 - Most researchers haven’t a clue how much it costs to feed a hood air

Sash Management

....continued

■ Use Sash Stops

- Place stops (which can be overridden) at desired working height of sash

■ Maintain Sashes

- Clean the sash glass periodically so it remains transparent
- Maintain counterweight systems and clean sash tracks for smooth sash movement

Sash Management

....continued

- Using fume hood controller features that you already bought
 - Reduce maximum airflow to CFM needed to get 100 FPM at sash stops
 - Set face velocity alarm to trigger when sash is raised a few inches above stops (need mute)
 - Use sash position sensor to alarm on excessive open area (need mute)

Sash Management

....continued

■ Other ideas

- Sticker hoods with reminders about proper use of sashes
- Mark sash positions with yearly cost to operate the hood
- Develop a “Safety Agreement” specifying owner and user responsibilities; to be signed by both

Dealing with High Heat Loads

- Evaluate the sources of heat and determine the largest producers
- Where heat producing devices have exhaust connection, use “elephant trunks”
- Relocate general exhaust grilles over heat sources; i.e.: refrigerators in biology labs
- Consider capture hood over uncontrolled sources

Additional Ideas

- Use “Unoccupied” settings during off hours-
 - Reduce minimum air change rate
 - Let room temperature setpoints “float”
 - Raise air handler cooling coil discharge temperature
- Add a “high energy” use alarm, triggered by excessive hood make up requirements

Using BMS Data to Maximize Energy Savings

- Most systems available today can record a wealth of data
 - Individual hood sash heights and exhaust volumes
 - Total lab exhaust volumes
- Consolidating the data is the difficult part because there is so much data
- The reason most people don't use data is they don't know how


BMS Suggestions

- Totalize (Integrate) Lab Exhaust on a monthly basis
- Establish target airflow volumes based on best practices
- Monitor actual use against targets
- Require retraining of offenders
- Controversial but done:
 - Charge back budgets of offenders

Full Time Expert Help

- The ability to “tap-in” to the BMS using the internet, now makes it easy to get expert help
- Services are available which
 - Automatically pull data from your system
 - Perform data crunching and real-time analysis
 - Benchmark energy use against “best practice” models and other users
 - Generate user advisories and reports

Internet Service Model



Internet Service Model

■ Data Retrieval

- Data transferred every 15 minutes

■ Data Reduction

- Exhaust use analyzed
- Cooling requirements analyzed
- Weather data projected
- Operating conditions compared to model
- Optimum setpoints determined
- Update model

Internet Service Model

- Hourly Operational Advice
 - Exhaust requirements compared to optimal
 - Continuous (not changing) high exhaust users
 - Cooling requirements; latent and sensible
 - Supply air set points
 - Static pressure setpoints
 - Control problems

Internet Service Model

■ Monthly Reports

- Energy use vs. Plan vs. Optimum
- Energy use by User, or Department
- Suggestions to reduce energy
- Plan for upcoming month, based on TMY data

■ Training

- Direct safety and energy awareness training at problem areas. Training can be delivered via Internet

In Summary-

- Critical Airflow Control Systems save energy; but are the means, not the end.
- Purchasing the system is the beginning, not the end of the road to energy savings
- Understanding how lab ventilation systems are intended to work is the key to getting the maximum energy savings

In Summary-

- Safety and Energy conservation goals are symbiotic and should be presented together in accordance with a unified plan
- Now, expert advise is available via the internet to help you get the most from your system.

Info about this presentation-

- Author: Ken Kolkebeck
- Contact
 - Facility Diagnostics
 - PO Box 32
 - Harrington Park, NJ 07640
- Phone Numbers
 - Tel: 201-784-8700 Fax: 201-784-5515
- On the Web
 - Site: www.facilitydiagnostics.com
 - Email: info@facilitydiagnostics.com
- Please take a moment to fill out our lab owner survey at www.facilitydiagnostics.com/lab21survey.htm