

Phoenix Controls
Corporation

Designing a Green Lab without Sacrificing Safety




Laboratory Controls Objectives

- ✓ **Fume hood capture and containment**
- ✓ **Laboratory pressurization**
- ✓ **Minimum ventilation control**
- ✓ **Temperature control**

Laboratory Usage Patterns

- ✓ **24 hour operation**
- ✓ **100% outside air**
- ✓ **Typically 1 hour per day of fume hood**


How Often are Hoods Used



Laboratory Usage Patterns

- ✓ 24 hour operation
- ✓ 100% outside air
- ✓ Typically 1 hour per day of fume hood
- ✓ **Occupancy in short segments**
- ✓ **Fume hood occupancy is independent**


Fume Cupboard Occupancy



Laboratory Usage Patterns

- v 24 hour operation
- v 100% outside air
- v Typically 1 hour per day of fume hood
- v Occupancy in short segments
- v Fume hood occupancy is independent
- v **Sash management varies widely**

Hood Leakage



What Is Diversity?

- v **Diversity of operation**
- v **Diversity types**
 - Phone company
 - Solar
 - Plumbing
 - Fume hood
- v **Diversity factor definition**
 - 75% or 25%?

Factors Affecting Diversity


- v **Control method**
- v **Number of fume hoods per manifold**
- v **Number of users per fume hood**
- v **Fume hood usage type**
- v **Cooling CFM requirements**
- v **Minimum ventilation requirements**
- v **Sash management**

A Diversity Example

- v Chemistry research laboratory**
- v 100 fume hood manifold**
- v 1000 CFM maximum hood flow**
- v 5:1 fume hood turndown range**
- v 10 hour day**
- v 1 hour/day fume hood presence (10%)**
- v Present sash position is 100% open**
- v Absent sash position is 50% open**

Constant Volume

Constant Volume Airflow



A Little Math


- ✓ **Fume hood occupancy is independent**
- ✓ **Binomial distribution as a tool**
- ✓ **Calculate fume hood diversity**
- ✓ **Number of fume hoods per manifold**
 - Hours per day at fume hood/total hours in day
 - Percent design criteria
 - Sash positions

Example With VAV Control

18 Occupied	X 1000 CFM	18,000 CFM
82 Unoccupied	X 500 CFM	41,000 CFM
<hr/>		
99% Design Airflow		59,000 CFM

99% of the time, airflow for this system will be at 59,000 CFM or less, *if people close their sashes to the 50% level.*

VAV Design Uncertainty




Example With Controls Based on Hood Usage

18 Occupied	X 1000 CFM	18,000 CFM
82 Unoccupied	X 300 CFM	24,600 CFM


99% Design Airflow	42,600 CFM
--------------------	------------

99% of the time, airflow for this system will be at 42,600 cfm or less, *if people close their sashes to the 50% level; 67,200 cfm or less if they leave sashes wide open.*


Controls Based on Hood Usage



Reducing Design Risk



Typical Airflows Comparison



Capital Savings Opportunities

- ✓ **Cooling systems**
- ✓ **Heating systems**
- ✓ **Reheat systems**
- ✓ **Supply and exhaust fans**
- ✓ **VFDs**
- ✓ **Ductwork and piping**
- ✓ **Other**

Controls Based Hood Usage Average Flow

10 Occupied X 1000 cfm 10,000 cfm

90 Unoccupied X 300 cfm 27,000 cfm

Average Airflow 37,000 cfm

Average airflow for this system will be 37,000 cfm, *if people close their sashes to the 50% level; 64,000 cfm if they leave sashes wide open.*

Expected Energy Savings Vs. Constant Volume

<u>Control</u>	<u>Savings</u>
Constant Volume	0%
VAV	0 - 65%
Hood Usage	30 - 80%

Life Cycle Cost Comparison*

System	1 Year	5 Years	10 Years
CV	\$1,700,000	\$2,900,000	\$4,400,000
VAV	\$1,815,000	\$2,475,000	\$3,300,000
Usage	\$1,161,000	\$1,605,000	\$2,160,000
<hr/>			
Savings	\$539,000	\$1,295,000	\$2,240,000

*Includes mechanical system first cost & and energy costs

Case Studies

- ✓ **Textile research facility (retrofit)**
- ✓ **Small southern university (retrofit)**
- ✓ **Western university (new)**

Textile Research Facility

- ✓ **26 existing fume hoods**
- ✓ **Wanted 26 more**
- ✓ **Options: replace mechanical system or construct a new building, or...**
- ✓ **Use diversity**
 - Doubled the hood count with the existing mechanical system
 - Saved time, money, and energy

Small Southern University

- ✓ **Many existing problems**
- ✓ **Wanted more fume hoods**
- ✓ **Initial costs estimates too high, so...**
- ✓ **Used diversity**
 - Added 20 new fume hoods without additional mechanical systems
 - Cured existing problems and saves energy
 - Cost 70% less than original estimates

Large Western University

- ✓ **New chemistry building (190,000 ft²)**
- ✓ **193 fume hoods (189,000 cfm)**
- ✓ **Diversity**
 - Extra mechanical system capacity
 - 53,000 cfm max hood exhaust flow
 - Major energy savings
 - 8 months payback



Thank You

Questions