THE VALUE OF COMMISSIONING IN PROVIDING HIGHLY EFFECTIVE LABORATORY VENTILATION SYSTEMS

Thomas C. Smith Exposure Control Technologies, Inc.

Dr. Robert Payne
U.S. Environmental Protection Agency

Primary Objective

Ensure safe operation at minimum possible operating costs while maintaining the capacity and flexibility to meet user demands.

Highly Effective System


- Safe Meets operating specifications and performance criteria.
- <u>Efficient</u> Minimum Energy Use and Lowest possible operating costs
- Dependable Available to meet user demands
- Flexible Adaptable to changing research needs

Benefits of Commissioning

- Verification of Design Assumptions
- Identification and Elimination of Problems (Pre-occupancy)
- Benchmark Operation
- Baseline Data for Maintenance
- Compilation of System Documentation

Commissioning Tasks

- Installation and Component Inspections
- Air Balance and Controls Calibration
- Hood Performance Tests
- System Operating Mode Tests
- Diagnostics and Problem Resolution
- Document Final Operating Parameters
- Develop Operations Manual



Operating Modes

Two Position Hood & Lab Control

- Occupied Mode (90% sash 100 fpm)
 - Lights On or
 - Sash Open
- Unoccupied Mode (60 fpm equivalent)
 - Lights Out and
 - Sash Closed

Factors Affecting Performance of Laboratory Fume Hoods

- Hood Installation Airfoil sill
- Exhaust Magnitude and Stability
- Room Air Supply (Cross Drafts)
- Room Temperature Control
- Operating Mode (Occupied / Unoccupied)


Reverse Flow and Escape

- Airfoil
- Baffle and Slots
- Loading Obstructions
- Flow Fluctuations
- Cross Drafts





Airfoil Installation





Flow Control and Stability

Unstable exhaust flow causes escape

- Variations between supply and exhaust affect area pressurization
- Variations affect accuracy of sensor calibration and value of BAS Information

Stable vs. Unstable Exhaust Flow







Flow Sensor and Control Damper Location

Good


Bad




Hood Exhaust - Flow Sensor Trend For D Module - Occupied - Damper Controlled by BAS - Hoods 3 and 4




Hood Exhaust - Flow Sensor Trend For D Module - Occupied - Damper Tuned For Hoods 3 and 4



FH D-561-A-1 Face Velocity Traverse Sash 90% Open (3 x 6 grid)



FH E-565-A-1 Face Velocity Traverse Sash 90% Open (3 x 6 grid)



Cross Drafts - Room Air Patterns

?

Complementary or Detrimental to Hood Performance


- Type of Diffuser
- Location and Orientation
- Volume and Terminal Velocity

Linear Slot Diffusers


Thermostat

Interlocking Service Door


Hood



Cross Draft Tests €




Front View



Side View




Cross Drafts Near Hood Opening with Original High Velocity Diffuser





Cross Drafts Near Hood Opening with New Low Velocity Diffuser



High Velocity / High Aspiration Diffuser

*Not Suitable For Lab Use



Lab Temperature Control

Diffuser Discharge Temperature vs.

Space Temperature

- Reheat Control
- Thermostat Location
- Room Air Patterns

Effect of Temperature Stratification

Fume Hood Performance During Heating and Cooling Mode Tests @ Temperature Equilibrium




Effect of Temperature Stratification

Fume Hood Performance During Heating and Cooling Mode Tests @ Full Cooling



Plot of Face Velocities while adjusting Heating and Cooling Modes



Problem Resolution

- Adjust Hoods and Airfoil Sills
- Relocate VAV Boxes
- Tune Controls and Calibrate Sensors
- Relocate or Replace Problematic Diffusers
- **Re-Balance Air Flows**
- Relocate Thermostats and Control Discharge Temperatures

Optimizing System Effectiveness

- Develop Clear Performance Specifications
- Pre-Qualify Components Mock-up if Necessary
- Customize Calibration and Commissioning Tasks
- Benchmark Operation

- Test and Maintenance Plan
- Periodic Operation and Energy Audits
- Renovation Procedures / Management of Change Plan
- Train Personnel